



Oceanid™

WATER RESCUE CRAFT

RDC Motor Mount Attachment Strap Placement



All 3 of the straps run from the frame under the inflated tube to the outside perimeter D rings. The two 6' straps run from beside the transom plate to the lower 1" D rings on the hand line. The single 4' strap runs from the top of the motor mount under the tube to the large 1.5" D ring at the top of the hand line.

Maximum engine size is 5 hp with a 15" short shaft.